



Model Number: 69-047

Sapphire Scientific [69-047] Ford Gas Fuel Tap Hook up Kit 1999-2003 for fuel injected truckmounts
Masterblend 730101

Manufacturer: Clean Storm

Truckmounted Fuel Line Installation Kit

- Kit includes fuel tap fittings for 1999 through 2003 Ford vans.
- Two barbs for fuel pick-up and return for recirculating systems.

*Kit does NOT include fuel pump.

Also marketed under part number
Sapphire 69-047
PBL69047
0200113001
Masterblend 730101

Factory min shipping charge is \$27 per kit.

Filled by part number and not by photo on web page.

Availability: This product was added to our catalog on Monday 28 May, 2012