



Model Number: 20150801

Clean Storm 20150801, Self Install Kit Add Pressure Gauge to a Pressure Washer 3000 psi

Manufacturer: Clean Storm

Clean Storm 20150801, Self Install Kit Add Pressure Gauge to a Pressure Washer 3000 psi

Note: If being installed on a hot pressure washer, you have to install on the cold side (before the heater)

Kit includes one each of the items below:

Pressure Gauge 3000 Psi Stainless Steel Back Mount 8.710-258.0

3/8" Mip X 3/8" Fip X 3/8" Fip Street Tee Brass 28247

3/8" Mip X 1/4" Fip Brass Bushing Adapter AKA 28104L A00168

Equipment: Carpet Cleaning Machines > Vacuum Cleaners > HEPA Concrete Dust Slurry Hazmat Vacuums >

PHY052-019 3/8" Mip X 3/8" Fip Steel Swivel Fitting / Not live 6M-6UFS

Availability: This product was added to our catalog on Saturday 01 August, 2015