



Model Number: Reverse6-50R

Clean Storm Reverse6-50R Power Joiner Step Up Inverter Dual 20 amp 120 volt outlets To 240 volt 3 wire 20amp 6-50R

Manufacturer: Clean Storm

Clean Storm Reverse6-50R Power Joiner Step Up Inverter Converts Dual 20 amp 120 volt outlets To 240 volt 3 wire 20amp 6-50R

#### Description

Power Cord Adapter Inverter (Reverse Converter) Takes two 120 volt outlets and allows you to use 240 volt appliances that uses under 20 amp @ 240 volts (under 4800 watts) Single phase current to NEMA 6-50R receptacle. Commonly used as an Welder plug. Fast and easy 240 volts.

Other 220 to 240 volt receptacles available including but not limited to: NEMA 6-30R, NEMA 6-50R, NEMA 10-30R, NEMA 14-30R, NEMA 14-50R, and many more

Perfect for electric cars, pressure washers, welders, plasma cutters, vapor steam cleaners, and other high powered equipment when 230 volt plugs are just not available.

Not for use on GFCI or LDCI 115/120 volt Outlets.

To use simply plug into different outlets and push the momentary button to test voltage. If the voltage read between 220 to 240 volts you are good to go. Not all outlet combinations will produce the correct voltage so you have to test before each use. If you push the voltage test button and it reads 120 volts, simply re-located one of the power cords to a different location and retest. Every job site location has the ability to provide plus or minus 230/240 volts. If you use 15 amp 115/120 volt circuits then you will only be able to operate 15 amp 230/240 volt equipment. If your pressure washer needs 23 amps @ 230 volts and you are plugged into 20 amp 115 volt outlets, you will need to turn the pressure down to lower the amp draw. Just turn the pressure regulator / unloader knob counter clockwise. The less pressure, the less horsepower is needed to turn the electric motor and this will lower the amp draw. On welders you will have to turn down the heat too.

Until both 120 volt power cords are connected to a 120 volt electrical source, it is electrically isolated from the electrical circuit of the male plug on the 2nd power cord. This protects the user from accidental shock through the exposed male plug contact.

Works with the following Zencar Level 2 EV Charger(240V,16A,28ft) Portable EVSE Home Electric Vehicle Charging Station Compatible with Chevy Volt, Nissan Leaf, Fiat, Ford Fusion.

MUSTART MU-P Level 2 Portable EV Charger (25ft Cable, 7.68KW), Electric Vehicle Charger Plug-In EV Charging Station with NEMA 6-50P (32 Amp).

Other 220 to 240 volt receptacles available including but not limited to: NEMA 6-30R, NEMA 6-50R, NEMA 10-30R, 14-30R, 14-50R, and more.

Specification

Plastic Box is 6" X 6" X 5"

Dual 12-3 X 25 ft power cords with dual 20 amp push breakers.

Green Light Voltage Notification

Rubber feet on bottom of box

Video

#### Additional Information

You must test both wall outlets with a receptacle polarity tester before use!

#### 20100823 Electrical Outlet Receptacle Tester 3 wire 120 volt

Note: User assumes all responsibility on use.

It is the users responsibility to check the inbound voltage, outbound voltage, and total amp draw to verify these are not going to be overloaded. The user agrees to test the amp draw of any appliance or machine that they plug into these converters to ensure they are not being overloaded. Meters are cheap and mistakes are expensive. You can purchase a meter at

<https://www.steam-brite.com/voltage-meter-multitester-p-6259.html>

User agrees to hold Steam Brite, its employees, and agents harmless in the event of any use of said use of converter. The user agrees to not hold SteamBrite and all employee against any problems that arise out of the use of said converters/ inverters. Remember, just because it plugs in does not mean it is OK to use!

Please remember the 80/20 electrical rule. If you are going to plug into a 15 amp outlet and draw long term the device needs to be under 80% of 15 amps = 12 amps max.

If I plug into dual 20 amp breakers long term then the 80/20 rules math is 20 amps X 80% = 16 amps max.

The Telsa Electric Cars use 14-50R outlets.

Manufacture 1 Yr warranty. Add optional 2 or 4 more years for a little more.

Owners Manual

Tips: One customer wrote, "I plugged into different walls, not the same outlet, and it did not work."

Answer: This is incorrect step / understanding.  
In order to have the power supply box work, it must be plugged into different phases.  
There are two phases of power in every home.  
Half of all the outlets are on left phase, and the other half is on right phase.  
You must land on one of each phase in order for the power supply to work.  
This means if I just randomly select two outlets in a home, I could be plugged into:  
two left side phases, 2 right side phases, or 1 of left + 1 right (correct use of power supply, depress phase locator button on the power supply box and will illuminate bright green on the phase locator light if you plugged in correctly.)  
If you look at the breaker panel (photo to the right) and notice the column of breakers on the left side and then a column on the right side.  
The way a breaker box is wired is the top left breaker is left phase, the 2nd from the top left straight down the left column is right phase, 3rd down is left column is left phase, 4th down is right phase. These breakers alternate phase location all the way down each column.  
The top right column of breakers works exactly the same way. You have to land on one left phase and one right phase to make this item work. It is OK to have landed on a pair of outlets that is left and right side and each is positioned anywhere in the breaker panel.

Since this power supply box will not work with GFCI or LCI outlets you can also replace a GFCI outlet with a standard wall receptacle.  
Optionally, if the two breakers you want to use are on the same phase, simply change the location of one of the two breakers to be in a different position in the column. This is very easy to do and only takes a screw driver (see video link below.)  
Go outside and turn off the breaker and turn off the breaker that is labeled as 'main'. Go back to the garage and take off the garage panel cover.  
Grab the breaker you want to relocate and simply switch positions with another breaker either one up or one down in the column. You can change the location of the breaker or change the location of the wire in the breaker (your choice.) This will put the breaker on a different phase. Again, see video below on how to do this.  
<https://youtu.be/BG9I-PokSdl?si=m06267ZWR54Tiknu>  
and  
<https://youtu.be/lzTV9t7bnH8?si=p1lgRxxO5gsEvmub>

Once you are on different phases, and press the momentary phase location button on your power supply box, the green light will be bright green telling you, you selected one left and one right phase and you are good to use this power supply box below the required amp draw of the wall outlets you plugged into.

#### Testimonials:

Used regularly by customers of <https://www.binzel-abicor.com>  
Optional Factory Installed 600 Volt, 80,000 Amp Surge Protection

Square D HEPD80 Whole Home Electronics Protective Device, AC Surge

Equipment: [Carpet Cleaning Machines](#) > [Vacuum Cleaners](#) > [HEPA Concrete Dust Slurry Hazmat Vacuums](#) >

Protection, Type 1 SPD, 120/240VAC, 1Phase 3Wire, 80kA

HEPD devices protect and provide surge suppression for important items that are not compatible with plug strips such as electric cars, concrete grinders, concrete compression testing equipment, floor sanders, concrete dust and HEPA vacuums, laser and light show equipment, table saws, washers, dryers, refrigerators, stoves, heating and air conditioning equipment, and lighting.

Availability: This product was added to our catalog on Friday 11 October, 2013